

Scheduling Recordings

Record the program you are currently watching

Press **REC** on the remote while watching a show.

If you've been tuned in from the beginning of the show, and you are less than an hour into the show, the recording will start from the beginning of the program. If you were channel surfing while watching, it will record from the last time you turned back to the show within the 60 minute record window..

Recording from the Guide

Highlight the show you want to record.

Press the **REC** button and a red ball will appear.

If it is a TV series, press the **REC** button again and 3 red balls will appear and the series will be recorded.

Press the **REC** again to cancel the recording.

To Extend the time of a recording

Press **Guide** on your remote

Highlight the show that is to be extended.

Press **INFO** on your remote.

Select **Record Options**

Select the blue box under **STOP RECORDING**

Options Include

- At scheduled end time
- 5 minutes after
- 15 minutes after
- 30 minutes after
- 1 hour after
- 2 hours after
- 3 hours after

Select one and press **OK** on your remote

There was a video in help, but it has been removed. If it is not restored watch this video on line <https://www.youtube.com/watch?v=1n3oy4MmF54>